

HOSHIZAKI

- 2. Relative humidity exceeding 60% may result in excessive condensation on the exterior.
- 3. The food temperature is controllable by turning over the food mounts.
 4. Product Code: S056-C174





1800



ITEM	Hoshizaki Counter Showcase	
MODEL	HNC-180BE-R-BLH	
POWER SUPPLY	1 Phase 220-240V 50Hz Capacity: 0.39kVA (1.63A)	
AMPERAGE	Rated: 1.0A Starting: 6A	
ELECTRIC CONSUMPTION	150W (Power Factor: 62%)	
HEAT REJECTION	420W	
PULL DOWN TIME	Approx. 30min.	Measured 20 mm above
(10°C)	(Ambient Temp. 30°C, No Load)	the food mount (normal
SATURATION	Approx. 5°C	position) located at the interior bottom center
TEMPERATURE POWER CORD	(Ambient Temp. 30°C, No Load)	interior bottom center
EFFECTIVE CAPACITY	72L	
OUTSIDE DIMENSIONS	$1800 \text{mm}(W) \times 345 \text{mm}(D) \times 270 \text{mm}(H)$	
INSIDE DIMENSIONS	$\frac{1445 \text{mm(W)} \times 345 \text{mm(D)} \times 276 \text{mm(H)}}{1445 \text{mm(W)} \times 288 \text{mm(D)} [\text{Floor}] \times 157 \text{mm(H)}}$	
EXTERIOR	Clear Glass, ABS Plastic, PVC Plastic	
INTERIOR		
	Clear Glass, ABS Plastic, Stainless Steel	
INSULATION INSULATION	Polyurethane Foam	
BLOWING AGENT	HFO-1233zd(E)	
DOOR	Sliding Glass × 4 [363mm(W) × 172mm(H)]	
REFRIGERATION SYSTEM	Convection Cooling	
DEFROST SYSTEM	N/A	
COMPRESSOR	Hermetic 110W	
CONDENSER	Fin and Tube type, Cooling Fan Motor provided	
EVAPORATOR	(Upper) Tube Type, (Lower) Pipe on Sheet Type	
REFRIGERANT	R600a/46g	
ELECTRIC CIRCUIT	Earth Leakage Circuit Breaker (with Overcurrent Protector) 15A	
PROTECTION	Earth Wire	
REFRIGERANT CIRCUIT PROTECTION	Motor Protector	
LIGHTING	LED	
WEIGHT	42kg (Gross: 60kg)	
PACKAGE	Carton (Wooden Pallet) 1880mm(W) × 415mm(D) × 517mm(H)	
ACCESSORIES	Food Mount x 5, Joint x 2, Drain Hose x 1	
OPERATING CONDITIONS	Ambient Temperature: 10 - 30°C Voltage Range: Rated Voltage ±6%	
*We reserve the right to make changes in specifications and design without prior notice.		

 Install the product properly in accordance with the instructions on location, water supply/drain connections and electrical connections stated in the instruction manual provided. Allow 10mm extra space at the installation site to meet any installation requirements (additional spacing is also required for proper air flow and pipe connections).

